


FOXEEER



MONSTER

1200TVL 16:9 Widescreen Camera

Instruction Manual



**WARNING:** Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury.



**Age Recommendation:**  
Not for children under 14 years. This is not a toy.

**NOTICE:** This product is only intended for use with unmanned, hobby-grade, remote-controlled vehicles and aircraft. FOXEEER disclaims all liability outside of the intended purpose and will not provide warranty service related thereto.

**SUPPORT:** Visit [www.foxeer.com/support](http://www.foxeer.com/support) to get more information.

2. Long press right button, time flicker, you can move time position, after setup, press center button to save, time stop flicker
3. Long press top button, you can setup user name, besides, OSD info enable or disable separately, press EXIT to save.
4. Long press bottom button, voltage flicker, you can move voltage position, after setup, press center button, you can adjust voltage if the OSD voltage is not same as real power, after setup, press center button, voltage stop flicker

FOXEEER	
0 1 2 3 4 5 6 7 8 9	
A B C D E F G H I J K	
L M N O P Q R S T U V	
W X Y Z ( ) : . < > /	
NAME :	ON
TIME :	ON
POWER :	ON
DEFAULT	
EXIT	

### 1. EXPOSURE

Move the cursor to "EXPOSURE", press the LEFT/RIGHT button to select "STD" or "BLC" mode.

#### 1. STD

Press the MENU to set camera brightness. It has "LOW", "MIDDLE", "HIGH" three modes for choice.

EXPOSURE	STD
SHUTTER MODE	AUTO
AGC	↓
AWB	ATW1
IMAGE ADJ	↓
PREV	NEXT
SAVE	EXIT

#### 2. BLC

Press the MENU to set camera intensity. It has "LOW", "MIDDLE", "HIGH" three modes for choice.

STD	
BRIGHTNESS	LOW
	RETURN

BLC	
INTENSITY	LOW
	RETURN

### 2. SHUTTER MODE

Move the cursor to "SHUTTER MODE", press the LEFT/RIGHT to select "AUTO" or "MANUAL". Camera normally works on "AUTO" mode.

EXPOSURE	STD
SHUTTER MODE	AUTO
AGC	↓
AWB	ATW1
IMAGE ADJ	↓
PREV	NEXT
SAVE	EXIT

#### MANUAL

"SHUTTER SPEED" can select from 1/25 to 1/1000000

SHUTTER MODE	
SHUTTER SPEED	1/25

### CAMERA-OSD SWITCH CONNECTION

